

FAULT FINDING 1 2





If you find you are experiencing problems with your tool, here are a few easy suggestions to help keep you going.

STEP 1

- Clean tool thoroughly
- Check battery is fully charged
- Check for nail jams
- Try the tool with different batch of nails
- Check fuel cell is in date.

STEP 2

ISSUE

SOLUTION

QUICK FIXES

- Fires two nails at once
- Intermittent firing.



- Check both nose lugs are in place and aligned.
- Check magazine is located and tight.
- Check nail strip for damage or compressed paper collation.

- Red light flashing
- Gas light red
- Leaking gas.

centre for repair.



STEP 3 ISSUE

SOLUTION

Intermittent firing

Won't fire properly.



Check fuel is in date (see base of fuel) and that the fuel cell is not too cold.

Fan running constantly



Check nose probe isn't stuck back and is free moving.

- Fan not working
- Solid red light
- Won't fire
- No power No lights on tool



- Check for damaged or disconnected cables under rear cap.
- Charger alternating red & green lights.
- Replace battery

Return to a service



WARRANTY

Your Paslode tool comes with a standard 2 year warranty, covering all components providing that Manufacturer's Operating Instructions have been followed, that no modifications have been made or non-original components or spare parts have been used, and that the tool has not been accidentally damaged or neglected.

Make sure to register your tool online Find further information in your toolcase.









WARRANTY